



Smartcare Repair Polymer

High Performance SBS Based binder

Description

Asian Paints Berger SmartCare Repair Poly is a high performance modified Styrene-butadiene rubber (SBR) based binder. It is recommended as a bonding agent for concrete/mortar in repair like spalled concrete-floors, chajjas, beams, slabs as it bonds old and new concrete surfaces strongly with plasters. It can also be used for waterproofing of toilets and bathrooms, small terraces. It also serves as a bond coat for repair patch work.

Uses

- For concrete/mortar repairs: RCC members, spalled concrete, repairing floors, beams and pre-cast slabs, chajjas
- As a polymer modified mortar/concrete in old and new constructions
- For waterproofing: Basement side walls, small roof terraces, sunken areas of toilets & bathrooms, chajjas & lift pits, balconies
- For Dampness & Efflorescence, Please use Asian Paints Berger SmartCare DampBlock 2k
- As a bond coat: For bonding of new concrete to old concrete and in repair patch work
- Floor screeds and toppings: Non-dusting floors

Characteristics/ Advantages

- Multipurpose: Robust product that is economical, easy to handle and has multiple applications
- Easy to mix: Compatible and faster mixing promoting worker efficiency
- Mortar modifier: Improved flexibility, low water cement ratio and resistance to water penetration
- Bonding: Bonds strongly to concrete, plasters, masonry, cementitious surfaces
- Cracking: Reduces cracking through enhanced mortar flexural strength
- Shrinkage: Reduces drying & aging shrinkage cracks
- Abrasion resistance: Increases wear resistance under rubber-wheeled traffic.

Packing

1, 5 & 20 Ltr

Dosage

- As a waterproofing coating: Mix proportion by weight; 1:2 (SmartCare Repair Polymer: Cement)
- As a mortar modifier: 7 % of SmartCare Repair Polymer by weight of cement
- As a bonding agent: Mix proportion by weight; 1:1 (SmartCare Repair Polymer: Cement)

Coverage

- As a waterproofing coating: 1.5-2 m²/kg in 2 coats
- As a mortar modifier: 3.5 kg of SmartCare Repair Polymer per 50 kg of cement
- As a bonding agent: 4.5-5 m²/kg per coat

Properties

Type	Modified SBR dispersion
Form	White Liquid
% Solids	40-42%
Specific Gravity	1 to 1.1

Application Method

Surface Preparation

- Remove all loose concrete, grease, mould oil or curing compound from concrete surfaces using wire brush, scrubber and suitable solvents (if required)
- Saw cut the concrete areas to a square or rectangular profile to a minimum 10mm depth at the extreme edges to promote enhanced bond strength
- Clean the concrete surface for the regions where breaking is an issue. Roughen the surface free of loose dust and particles
- Saturate the surface thoroughly with portable water prior to priming. Make sure to remove any excess of water if present

Waterproofing coating

- Use SmartCare Repair Polymer as a solution for repairs and preventive waterproofing solutions only
- For treating issues of dampness & Efflorescence, Asian Paints Berger SmartCare DampBlock 2k is

recommended.

- 1:2 ratios by weight of Asian Paints Berger SC Repair Polymer to cement ratio is maintained for using it as a waterproofing slurry coat
- Mix for 2-3 minutes to avoid air entrapment. Slowly keep on adding cement to SmartCare Repair Polymer until the required consistency is achieved
- Mechanical stirrers are recommended for efficient mixing
- Apply 2 coats of the mix by brush in a span of 4-6 hours on the prepared concrete substrate
- It is recommended to cover the coating with a protective screed to the desired slope & thickness

Repair mortars & Renders

- A suitable mix ratio for patching repair mortar or render is as follows:
- Mix Design - Cement: Sand in 1:3 proportion and add Asian Paints Berger SC Repair Polymer 7% by weight of cement and required amount of water

Bond coat

- For bond coat application mix Asian Paints Berger SC Repair Polymer and cement in the ratio of 1:1
- Brush apply 1 or 2 continuous coat of the mix on the prepared concrete substrate
- Ensure to overlay the repair mortar when the bond coat is still tacky. Recoat again if the

tackiness is lost

Precautions & Limitations

- Recommended dosage to be followed to achieve desired results
- When working in hot temperature conditions, extra water may be added to the repair mortar to compensate for the
- evaporation loss & make the mortar workable
- Surface should be in Saturated surface dry conditions
- In case of bond coat application make sure the repair mortar is overlaid when the surface is tacky. Recoat again if the tackiness is lost
- Stagnant water should be strictly avoided for application purpose

Shelf life

12 months from the date of manufacture when stored in original un-opened pack under normal conditions

Note: The information supplied in our literature or given by our employees is based on extensive experience and, together with that supplied by our agents or distributors, is given in good faith to help you. Our company policy is one of continuous Research and Development; we therefore reserve the right to update this information at any time without prior notice. We also guarantee the consistent high quality of our products; however, as we have no control over site conditions or the execution of work, we accept no liability for any loss or damage which may arise as a result thereof.

Version No. V06 02/23. Please note that this datasheet supersedes all previous versions UAE



For enquiries, feedback and complaints please contact or write to us at
Oman : 800-01790 | weassure.oman@asianpaints.com
U.A.E : 800-27237437 | weassure.uae@asianpaints.com
Bahrain : 800-08098 | weassure.bahrain@asianpaints.com
Qatar : +974-44693489 | weassure.qatar@asianpaints.com