DESCRIPTION

Causeway Wood stain is a transparent colour solution that is used for decoration of wooden surfaces. Causeway Wood stain enables you to have your choice of wooden shade without damaging the beautiful character of wood grains. Causeway Wood stain contains dye pigments in aromatic solvent.

- Concentrated
- Transparent Colours
- Solvent Based

TYPICAL USES

- Wood furniture's, doors, cabinets etc.
- Interior & exterior Wooden walls

APPLICATION

- Apply over primed surfaces
- Method of application
  - Conventional Spray
  - Brush

APPLICATION INSTRUCTIONS

- Product is ready for use.
- Topcoat clear is necessary as wood stain cannot last on its own.

HEALTH & SAFETY

Always keep paint out of reach of children. Ensure good ventilation during application and drying. Do not smoke while painting. Highly flammable. Store in a cool dry place away from heat and sparks.

CAUSEWAY PAINTS

TECHNICAL DATA SHEET
CAUSEWAY WOOD-STAIN

TECHNICAL DATA

○ COLOR	: Transparent Colour (Teak, Mahogany, Walnut & Jackwood)
○ COMPONENTS	: Single
○ FINISH	: Matt
○ CURING MECHANISM	: Solvent evaporation
○ ODOUR	: Mild Aromatic
○ SPECIFIC GRAVITY	: ~ 0.900
○ THINNER	: Do not thin this product
○ MIXING RATIO	: N/A
○ SPRAY VISCOSITY	: 12 sec (Ford 4)
○ THEORETICAL COVERAGE	: Depends on the wood
○ DRYING TIME	: 5 min (Touch dry)
○ RE-COATING INTERVAL	: If necessary (10 min)
○ SHELF LIFE	: Best before 24 months

PACKING

○ 300 ml ○ 1 Litre ○ 4 Litres

Issue Date: 24/10/2016 **Rev: 01**

The Technical Data is provided only as general advice. However, since service and applications conditions are beyond our control, we do not accept liability relating to coverage, performance and injury arising from the use of our products based on these data. The above information may vary from time to time and we reserve the right to modify the data without prior notice.