

Apcolite Premium Emulsion

Asian Paints Apcolite Premium Emulsion gives a rich smooth finish to the wall. It is the best buy for the money you spend and will make your interior walls colourful and durable.

PRODUCT BENEFITS

Excellent Opacity

Apcolite Premium Emulsion is a high opacity emulsion paint. Since it comes with HFT (High Film Thickness) technology with highest quality light fast pigments & Vinyl Acrylic Polymer it gives the best hiding



Long lasting film

Apcolite Premium Emulsion has a long lasting film that keeps your house as good as new for a long time.

Fungus and mildew resistance

Apcolite Premium Emulsion protects your walls from Fungal growth.

Excellent Flow and Leveling

Wide Range of Factory Made Shades



WATER BASED

asianpaints


LEAD FREE* GUARANTEE

* All Asian Paints products contain no added Lead, Mercury, Arsenic or Chromium from April 2008.




PRODUCT FEATURES

WASHABILITY



AVAILABLE PACKS




Shelf life: 3 years from date of manufacture in original tightly closed containers away from direct sunlight and excessive heat.

COLOURS AVAILABLE


49+*

Factory Made Direct Shades

*Light & Pastel shades can be tinted from the Asian Paints Colour World outlets



FINISH



Refer to sheen levels in technical details

SPREADING RATE

On primed masonry surface by brushing/ rolling



1 COAT

On previously painted surfaces to get the one coat hiding up to 160sqft per liter/ per coat



2 COATS

On new surfaces up to 125 sq.ft per liter by two coats

**Actual coverage may vary from the quoted coverage due to factors such as method and condition of application and surface roughness and porosity.

HOW TO APPLY

PRE PAINTING STEPS



PLASTER New masonry surfaces must be allowed to cure completely. It is recommended to allow 28 days as the curing time for new masonry surfaces.



CLEANING Surface should be free from any loose paint, dust or grease. Growths of fungus, algae or moss should be removed by wire brushing and water. In case of areas having excessive dampness use Asian Paints DampBlock to limit further dampness. When the underlying surface exhibits chalkiness, in spite of thorough surface cleaning, use Asian Paints SmartCare Exterior Sealer.



FILLING FOR CRACKS For filling cracks upto 3mm use Asian Paints SmartCare Crack Seal.



FILLING FOR HOLES & DENTS In case of dents and holes use Asian Paints Acrylic Wall Putty or white cement and fine sand in the ratio 1:3

For interior surfaces or substrates that are subjected to continuous seepage or dampness, kindly use Asian Paints SmartCare Damp Block before the top coat application.

PAINT APPLICATION PROCESS

APPLICATION	CODE	THINNER	DILUTION %	APPLICATION VISCOSITY ¹	RECOATING PERIOD
STEP 1 SANDING SAND THE SURFACE WITH SAND PAPER 180 AND WIPE CLEAN					
STEP 2 ASIAN PAINTS TRUCARE WALL PRIMER BRUSH / ROLLER / SPRAY	AP60	WATER	Brush/ Roller/ Spray 80% - 100%	50-60 KU	MINIMUM 4 HRS
STEP 3 AP KOTE/ SKIM KOTE PUTTY PUTTY KNIFE	AP33	WATER	Based on Requirement	N/A	8 - 12 HRS
STEP 4 SANDING SAND THE SURFACE WITH SAND PAPER 180 AND WIPE CLEAN					
STEP 5 ASIAN PAINTS TRUCARE WALL PRIMER BRUSH / ROLLER / SPRAY	AP60	WATER	Brush/ Roller/ Spray 80% - 100%	50-60 KU	MINIMUM 4 HRS
STEP 6 SANDING SAND THE SURFACE WITH SAND PAPER 320 AND WIPE CLEAN					
STEP 7: FOR REPAINTING FOR FRESH WALLS 1 COAT OF APCOLITE PREMIUM EMULSION BRUSH / ROLLER / SPRAY	PA01	WATER	35 - 40% for single coat application	60 KU	3 - 4 HRS
STEP 8 SECOND COAT APCOLITE PREMIUM EMULSION BRUSH / ROLLER / SPRAY	PA01	WATER	40 - 50% for two coat application	60 KU	3 - 4 HRS

1. As measured through a Ford cup.

2. Recoat period is quoted for 25°C and 50% Relative Humidity, these may vary under different conditions.

3. For best results and to avoid patchiness (lime blooming), Asian Paints TruCare Wall Primer is recommended under the following conditions:

- When the underlying surface exhibits chalkiness inspite of thorough surface cleaning
- In areas where the water table is high, leading to excessive seepage/dampness
- In coastal high humid areas.

*Mineral Turpentine Oil

HOW TO CHOOSE COLOURS

Browse through Asian Paints colour tools to help you find the right colour combination



*These shades are for reference only. Please refer to the Colour Spectra or Colour Palette for correct shade reference

ADDITIONAL INFORMATION

VOC CONTENT



Asian Paints Apcolite Premium Emulsion meets the LEEDS VOC criteria as per Indian Green Building Council version 1.0 as tested at Shiram Institute for Industrial Research. Tested for Premium Emulsion White (shade code 0908)

PRECAUTIONS

- > Do not apply when ambient temperature is less than 10°C or if the temperature might drop to this level within 4 hrs of application.
- > Do not over-thin or over-extend the brush.
- > Tint using Asian Paints machine colourants only
- > Stir well and strain before use.
- > Tinted paints need thorough shaking immediately after tinter addition as well as before use.

POST PAINTING CARE

For best performance ensure dry dust cleaning at regular intervals . Allow drying time of 3 weeks for proper film formation before any sponge cleaning with mild soap solution.

TECHNICAL DETAILS

- a. Drying time: Surface dry time 30 min
- b. Sheen levels: 2 - 5 at 60 deg GH
- c. Flash point IS101/1987 Part 1, Sec 6: NA
- d. Stability of thinned paint: To be used within 24 hours

SAFETY FEATURES

- > Kindly refer to the MSDS for Asian Paints Apcolite Premium Emulsion which gives detailed information on safety measures while handling the paint, which is available on request.
- > Store the container with the lid tightly closed in an upright position, in a cool, dry place
- > Keep out of reach of children and away from eatables.
- > May be harmful if swallowed. In case of ingestion seek immediate medical attention.
- > Wear eye protection during application. In case of contact with eyes, rinse immediately with plenty of water and seek medical advice.
- > In case of skin contact immediately wash skin with soap and plenty of water. Get medical attention if irritation develops or persists.
- > Do not breathe vapour or spray. It is recommended to wear suitable nose pad during sanding and surface preparation to avoid dust inhalation.
- > Do not pour leftover paint down the drain or in water courses.
- > In the event of spills, contain spillage using sand or earth.
- > No added Lead, Mercury or Chromium compounds.